

R E M O T E

Start

# 1. START

Make sure your products are up to date:  
Launch the Devialet App > Settings > System Update

Switch on the remote using the button underneath




Bring the remote near your Devialet product  
until it emits a sound



Remote will undergo updates time to time.

You should not use Remote when this icon appears on the screen

## 2. FUNCTIONS



\*To exit standby mode, simply press the power button on the back of your speaker.

### 3. RESET

To pair Remote with a new Devialet product, launch the pairing mode by pressing the Previous and Next buttons simultaneously for 3 seconds.

Then, place Remote near your Devialet product until it emits a sound.

